


Quick Exhaust Valve

Working Pressure

: 0.05 ~ 1.2MPa





Quick Exhaust Valve

Working Pressure

: 0.12 ~ 1.0MPa



Product Description

The valve is generally installed on the pipeline between the cylinder and reversal valve and near the cylinder, which directly discharge the air from cylinder without passing the reversal valve and thus to achieve the goal of fast reversion of cylinder. The effect on improving cylinder speed is especially obvious.

P: Connect reversal valve export

A: Connect cylinder R: Connect muffler

Ordering Code

